

ChargeLite™ Wall

USER MANUAL



Contents

	Page No
Introduction	3
Important Actions	4
Getting Started	4
Charge Only Set Up	5
Warranty	6
Care & Maintenance	6
Health & Safety	7
Key	8
Helpful links	9
Safety declaration	10
CE conformity	11

2024 ChargeLite™ Wall User Manual V1

Introduction

Congratulations and thank you for purchasing a ChargeLite™ Wall unit from the LapSafe® ChargeLite™ range. Your product comes with a lifetime parts and labour warranty which you will need to activate immediately.

This manual guides you through the set-up and correct use of your product.

For instructions on how to install your ChargeLite™ Wall unit please refer to your installation guide supplied with your unit for further information.

Box contents:

1 x ChargeLite™ Wall 16

1 x Mounting bracket (supplied fitted to the unit)

1 x Quick start guide

Important Actions

Upon delivery of your new ChargeLite™ Wall unit you must:

Take a note and store in a safe place your product serial number which can be found located on the top of the unit. The silver plate will hold your serial number that begins with CL.

You will need to quote this number for all enquiries relating to your unit. Take a note of your key number located on the key itself and store this in a safe and secure place. You will need this if you wish to order additional keys.

Visit lapsafe.com/activate to activate your Lifetime Warranty.

Your warranty will not be valid unless you do this.

Read the section on Health & Safety

Getting Started

There are ventilation holes through the base and on the top of the ChargeLite™ Wall unit, and care must be taken that none of these holes are obstructed. The front left door of your ChargeLite™ is unlocked using the key with the white key cover, the right door has a separate key with a black key cover, or gain entry with your PIN or MIFARE® card. (Optional left-hand door only). The front left door is for everyday working access to the cabinet.

The key can be removed once the door is open, this will prevent the door from closing fully whilst it is unlocked. The right-hand door should not be considered as day-to-day access to the cabinet but used for initial setup by a responsible/authorised person.

Charge Only Set Up

1. Open both front doors.
2. You will find power strips for your AC adaptors in the right side compartment.
3. Some AC adaptors can be described as 'in-plug' where they plug directly into a socket and the charging lead goes directly to the device, and others can be described as 'in-line' where they have a mains lead between the power socket and the AC adaptor and then a charging lead going to the device.

4. For 'in-plug' AC adaptors simply feed the charging lead behind the divider onto a shelf.



In-plug AC Adaptor

5. If you are using 'in-line' AC adaptors you have the choice to feed the mains lead behind the divider and place the adaptor on the shelf with your devices or to leave the AC adaptor in the right side compartment and just feed the charging lead behind the divider onto the shelf.



In-Line AC Adaptor

6. We provide cable ties to help with cable management and we recommend that the charging lead is secured to the shelf in a suitable position in order to prevent it 'working' its way off the shelf.

Repeat these steps until your wall unit is fully loaded.

NOTE: Maximum loading 100Watt (rated capacity) per socket.
(400Watts (rated capacity) per power strip).

Warranty

The ChargeLite™ range comes with Lifetime Parts & Labour Warranty.
Full Details of our warranty are on our website lapsafe.com/warranty.

To activate your FREE Lifetime* Parts and Labour Warranty, please go on-line and register at **lapsafe.com/activate**.

Care & Maintenance



Do's

- Lock your ChargeLite™ Wall unit when not in use
- Keep your keys in a safe place and not in the same room as the wall unit
- Read the Health and Safety guidelines in the user guide and share this information with all users
- Activate your warranty at lapsafe.com/activate
- Unplug charging leads before taking laptops out of the unit.



Don'ts

- Do not leave keys in the doors
- Do not remove doors
- Do not try to modify the unit in anyway without contacting LapSafe® first to check that it is safe to do so.

Health & Safety

All products manufactured by LapSafe® have been thoroughly tested and certified by an authorised and INDEPENDENT testing house before sale.

Full CE compliance, which includes the requirements of LVD and EMC directives, is a STANDARD FEATURE of any solution manufactured by LapSafe®, as are many more built in safety features. CE Marking can be found on the product serial number plate, usually at the lower rear of the cabinet. CE Declaration of Conformity Certificate is issued with each product in the User Guide Pack.

Please be advised of the following safety advice: At no time are the service areas of the ChargeLite™ Wall unit to be opened by anyone other than an authorised person.

WARNING: Hand and power tools can be dangerous when used incorrectly and the user should be trained to use work equipment and have an understanding of the HSE leaflet, 'using work equipment safely' (INDG229). Please also refer to the manufacturers documentation for specific information about the equipment you are using.

WARNING: Because surfaces vary widely and the fitting location and method of fixing is out of LapSafe®'s control, it is imperative that you consult with appropriate engineering, architectural, or construction professional to ensure that your ChargeLite™ Wall unit is mounted properly and that the substrate is suitable to handle applied loads.

WARNING: Before removing or accessing any service area unplug or turn the power to the unit off.

Explanation of Symbols



Electrical Hazard:

This unit is recommended for use with a switched wall socket



Caution:

Before connecting or removing the mains plug, ensure that the wall socket is in the 'off' position



No Liquid:

Avoid all contact with liquids



Refer to User Manual:

See user manual for guidance



Protective Earth icon



Disposal:

The crossed-out wheeled-bin symbol on your product, battery, literature or packaging reminds you that all electrical and electronic products and batteries must be taken to separate collection recycling points at the end of their working life.

Do not dispose of these products as unsorted municipal waste: take them for recycling. For info on your nearest recycling point, check with your local waste authority.

Helpful Links



Support Enquiries:

lapsafe.com/support/enquiry

support@lapsafe.com

0800 130 3456



Warranty: lapsafe.com/support/activate-warranty

Warranty Details: lapsafe.com/warranty



Replacement Keys: lapsafe.com/support/keys

Declarations



Safety Declaration

Recent guidance from the Health and Safety Executive regarding "Laptop computer charging trolleys safety alert" requires interpretation from each manufacturer as regards to their product compliance. The HSE statement can be found at: www.hse.gov.uk/services/education/safety121009.htm

CE Testing, Conformity and Declaration of LapSafe®

At LapSafe® we are proud to confirm that ALL of our electrical products, going back over ten years, have been thoroughly tested and certified (by an authorised and INDEPENDENT testing house) and accordingly have been clearly CE marked.

Full CE compliance, which includes the requirements of LVD and EMC directives, is a STANDARD FEATURE of LapSafe®, as are many more "built in" safety features. CE Marking can be found on the product serial number plate, usually at the lower rear of the cabinet. CE Declaration of Conformity Certificate is issued with each product in the User Guide Pack.

You may obtain further copies of the certificate specific to your product and serial number, or any further information and advice, upon request to our Customer support- call direct 01787 226147 or FREEPHONE the switch board on 0800 130 3456 or email support@lapsafe.com.

Rest assured that your LapSafe® Product has been designed and built with Safety as the highest priority since we first introduced the concept of the "mobile laptop trolley" into the UK market in the last century. This is, indeed, why we are called "Lap SAFE".

Residual Voltage

The HSE has raised a concern (having identified at least one particular manufacturer's trolleys with this "characteristic") that many manufacturers' trolleys (if indeed not the vast majority), may have a momentary residual voltage on the pins of the mains plug and that this could, if you touched the pins within a second or two of unplugging, result in an electric shock.

LapSafe® have been designed from the outset with safety internal circuitry as standard so as NOT to retain or present any significant residual voltage in this way. In fact, it is virtually impossible to get any such significant electric shock from our cabinets in normal use.

However, regardless of how safe any particular trolley may be, we endorse the recommendations for employing common sense practice as a generic rule for any mobile electrical appliance, such as switching off the mains socket before unplugging the power leads and NOT moving the trolleys without disconnecting and unplugging the power leads at both ends. Two of the wheels are fitted with locks as standard and should be kept locked as a reminder when power is connected and as a general safety rule as per the user instructions supplied with each cabinet.

For further information call LapSafe® on
0800 130 3456 or visit our website at lapsafe.com.

*"Lifetime" range from January 2010



0800 130 3456
www.lapsafe.com

LAPSF076_23052011V2



EU Declaration of CE Conformity

EU Declaration of CE Conformity

to Council Directive 89/336/EEC
Amendment 2004/108/EC
&
to Council Directive 73/23/EEC
Amendment 2006/95/EC

Equipment Description:

Laptop Battery Charging Unit

Device Name:

LapSafe® ClassBuddy™ Range

Manufacture Address:

LapSafe®
Unit 3 Wakes Hall Business Centre
Wakes Colne
Colchester
Essex
CO6 2DY

European Standards:

IEC 60950-1:2005
EN 60950-1: 2006 + A1: 2010

Declaration: We hereby declare that the stated equipment complies with the required Emission, Immunity and Electrical Safety standards stated above.

Issue Date:

4 December 2012

Authorised by LapSafe®:

John Hutton

Position:

Director

LAPFWL_M230421



Lapsafe® Self-Service Solutions Ltd

3 Wakes Hall Business Centre,
Wakes Colne, Colchester, Essex CO6 2DY



0800 130 3456



sales@lapsafe.com



lapsafe.com